
Zusatzbetriebsanleitung

**Sonderausstattungen für
Individualfahrzeuge BMW 7er Reihe**

BMW AG

Aus den Anlagen, Abbildungen und Beschreibungen können keine Ansprüche abgeleitet werden. Irrtum vorbehalten.

Änderungen in der Konstruktion, Ausstattung und beim Zubehör bleiben im Interesse der Weiterentwicklung vorbehalten.


Diese Zusatzbetriebsanleitung informiert Sie über die Sonder- und Spezialausstattungen Ihres BMW 750iL und ersetzt nicht die Betriebsanleitung der Serienfahrzeuge.

Auf den folgenden Seiten wird Ihnen gezeigt, wo diese speziellen Details eingebaut sind und wie sie zu bedienen sind.

Die Ausstattung Ihres Fahrzeugs ist vom Auftrag/Lieferumfang und Länderspezifikationen abhängig. Sonderausstattungen die in dieser Broschüre beschrieben werden, müssen also nicht generell in Ihrem Fahrzeug eingebaut sein.

Lesen Sie diese Broschüre damit Sie die zusätzlichen Annehmlichkeiten voll nutzen können.


Viel Freude beim Reisen wünscht Ihnen Ihre
BAYERISCHE MOTOREN WERKE AKTIENGESellschaft



Zusatzarmaturen Instrumententafel


1. Schalter für Zentralverriegelung EIN/AUS
2. Drucktaste um den Fernstart zu aktivieren
3. Schalter für Gardine Tür hinten links AUF/ZU
4. Schalter für Gardine Tür hinten rechts AUF/ZU
5. Mikrofon für Außenlautsprecher
6. Lautstärkenregelung für Wechselsprechanlage
7. Schalter für Wechselsprechanlage EIN/AUS
8. Sprechaste für Außenlautsprecher
9. Schalter für Gardine Heckscheibe links AUF/ZU
10. Schalter für Gardine Heckscheibe rechts AUF/ZU
11. Drucktaste für Elektronische Dämpfer Control (EDC)*
12. Drucktaste für Automatische Stabilitäts Control /ASC)*
13. Drucktaste für Park Distanz Control (PDC)*

* Funktions- und Systembeschreibung siehe Betriebsanleitung für Serienfahrzeuge.



Zusatzarmaturen in der Fondmittelkonsole

1. Schalter für Fondklimaanlage
2. Schalter für Gardine Tür hinten links AUF/ZU
3. Schalter für Gardine Tür hinten rechts AUF/ZU
4. Schalter für Gardine Heckscheibe links AUF/ZU
5. Schalter für Gardine Heckscheibe rechts AUF/ZU
6. Schalter für Kamera Zoom
7. Schalter für Bildschirmabdeckung
8. Drucktaste für Video-Casettenfach AUF
9. Schalter für Safe AUF/ZU bzw. Telefaxgerät aus-/einfahren
10. Schalter für Zentralverriegelung EIN/AUS
11. Mikrofon für Außenlautsprecher
12. Sprechaste für Außenlautsprecher
13. Tasten für Codierschloß
14. Schalter für Kopfstützenverstellung Beifahrersitz
15. Schalter für Sitzverstellung Beifahrersitz



Fondklimaanlage

Die Fondklimaanlage arbeitet unabhängig von der Klimaautomatik im Armaturenbrett.

Durch die zusätzlichen Luftaustrittsschächte im hinteren Bereich des Dachhimmels wird auch im Fond eine ausreichende Kühlung und damit ein ermüdungsfreies Reisen ermöglicht.


Die Bedienung der Anlage erfolgt über den Drehschalter (1) in der Fondmittelkonsole.

Betätigung ab Zündschlüsselstellung 2.

Stellung 0: Anlage ausgeschaltet


Stellung I: Anlage eingeschaltet, minimale Gebläseleistung.

Weiterdrehen in Stellung II oder III erhöht die Gebläseleistung.




Bareinheit

Die im Bereich der Fondarmlehne eingebaute Bar besteht aus dem Ablagetisch (3), der Kühlbox (2) mit Beleuchtung und einem Ablagefach (1).



Ablagetisch

Knopf drücken und Ablagetisch nach vorn klappen.



Kühlbox

Kühlboxbetrieb:

Schalter in Pfeilrichtung drehen.

Stufe 0: Kühlung ausgeschaltet.


Stufe 1: Kühlung eingeschaltet, Kühlboxbeleuchtung an.

Weiterdrehen auf Stufe 2 bis 5 erhöht den Kühlgrad.

Kühlbox reinigen:

Kühlboxeinsatz ausschließlich mit weichem Lappen und lauwarmem Wasser, evtl. mit Zusatz von Geschirrspülmittel auswaschen.

Anschließend mit weichem Tuch trocknen.




TV/Videoanlage

TV/Videobetrieb

Bildschirmabdeckung öffnen (siehe Zusatzarmaturen Fondmittelkonsole).

TV-Gerät einschalten (Pfeil).

Weitere Informationen über die Bedienung und Handhabung der Video-Anlage entnehmen Sie bitte der separaten Bedienungsanleitung.




Video-Cassettenfach

Cassettenfach öffnen: (siehe Zusatzarmaturen Fondmittelkonsole).

Hinweis:

Das Video-Casettenfach kann nur bei vollständig geschlossener Schublade ausgefahren werden.



Schublade in der Fondmittelkonsole

In der Schublade ist je nach Auftrag/Lieferumfang die Telefaxanlage oder der Safe untergebracht.

Schublade öffnen:
(siehe Zusatzinstrumente Fondmittelkonsole Seite 3).


Telefaxanlage

Die Telefaxanlage ist mit einem Akustikoppler (1) ausgestattet.

Achtung:

Die Telefaxanlage ist nur bei vollständig ausgefahrener Schublade betriebsbereit.

Weitere Informationen über die Bedienung und Handhabung der kompletten Anlage entnehmen Sie bitte der separaten Bedienungsanleitung.



Safe

Schloß codieren:

Am abgebildeten Zahlenfeld (nur bei geöffneter Schublade sichtbar) können Sie ihre persönliche Geheimnummer (bis zu sieben Stellen, beginnend links in Fahrtrichtung) eingeben.

Achtung:

Persönliche Geheimnummer unbedingt merken!

Beispiel: 0 0 1 2 0 0 0

Zum Öffnen dieses Codeschlüssels müssen Sie über die Tasten (Pfeil) lediglich die Zahl 1 2 0 0 0 eingeben. Nullen vor der ersten Zahl können ignoriert werden.

Jeder Tastendruck wird durch einen kurzen Signalton quittiert. Bei Eingabe der letzten korrekten Zahl entfällt dieser Signalton zur Erkennung der korrekten, kompletten Zahlenfolge.

Erfolgt innerhalb von vier Sekunden keine Betätigung des Schalters – **Schublade AUF** –, muß erneut der komplette Code eingegeben werden.

Bei falscher Eingabe der Zahlenfolge Taste – **R** – (Reset) drücken.


Die Anzahl der zulässigen Versuche zur Eingabe des korrekten Codes ergibt sich aus der Zahl der codierten Stellen plus eins. In unserem Beispiel wurde eine 5stellige Zahl gewählt, so daß insgesamt sechs Versuche möglich sind.

Wurde auch beim sechsten Versuch ein falscher Code eingegeben ist die weitere Bedienung für 10 Minuten gesperrt. Werden während dieser Zeit (10 Minuten) Tasten betätigt, verlängert sich die Sperrzeit um die Zeitspanne in der eine Taste gedrückt gehalten wurde.

Hinweis:


Bei Auslieferung des Fahrzeugs ist der Code 0 0 0 0 0 0 0 eingegeben.

Durch Drücken der Taste – **0** – im Tastenfeld (Pfeil) Schloß entriegeln. Erfolgt innerhalb von vier Sekunden keine Betätigung des Schalter – **Schublade AUF** –, muß erneut die Taste – **0** – gedrückt werden.



Box für Reinigungstücher (Kleenexbox)


Box in Pfeilrichtung herausziehen, neue Packung in die Blende einlegen, Box unten an die Türverkleidung ansetzen und nach oben klappen.



Ablagefach vorn

Öffnen: Griff ziehen.

Schloßbetätigung mit einem Zentralschlüssel.



Fernbedienung/ Fernstartanlage (FSA)

Mit der Fernbedienung kann der Motor des Fahrzeugs bis aus einer Entfernung von ca. 500 m gestartet werden.


Achtung:

Die Fernbedienung ist nur bei aktiviertem Schalter (siehe Seite 2 Position 9) funktionsfähig.

Taste 1 und 4 drücken:
Diebstahlwarnanlage wird entschärft, Zentralverriegelung entriegelt, Motor gestartet.

Taste 2 und 4 drücken:
Überfallalarm wird ausgelöst.

Taste 3 und 4 drücken:
Diebstahlwarnanlage löst aus, kein Motorstart möglich.



Ladesteckdose im Motorraum


Bei Ladevorgang über die Ladesteckdose (1) werden beide Batterien (Starter und Zusatzbatterie) gleichzeitig aufgeladen.

Das Anschließen kann nur in Verbindung mit einer handelsüblichen Steckkupplung nach DIN 14 690-C erfolgen.

Hinweis:


Batterie im Fahrzeug nur bei abgestellten Motor aufladen. Ladespannung darf 15 Volt nicht überschreiten. Ladevorrichtung muß der VDE entsprechen. Bei Rückfragen wenden Sie sich bitte an den BMW-Service.

Weitere Einzelheiten finden Sie in der Fahrzeug-Betriebsanleitung.




Kofferraum-Notentriegelung

Die Heckklappe kann von **innen** durch Ziehen am Kordelband (Pfeil) entriegelt werden.



Trennwand im Kofferraum

Zum Herausnehmen der Trennwand muß die Rändelschraube (Pfeil) gelöst und bei Fahrzeugen mit einer Fondklimaanlage zusätzlich die Verkleidung des Kompressors demontiert werden.




Sicherungen

Die Sicherungen für Sonderausstattungen sind hinter der rechten Gepäckraumseitenwand angebracht.

Bodenmatte anheben, Schnellverschlüsse öffnen und Seitenverkleidung abnehmen.

Die Sicherung des defekten Verbrauchers mit der Kunststoff-Pinzette (im Sicherungskasten Gesamtfahrzeug im Motorraum links) aus der Fassung ziehen.


Durchgebrannte Sicherungen (erkennbar am geschmolzenen Metalldraht) durch eine neue mit gleicher Amperezahl ersetzen.



Relais im Kofferraum rechts

Bodenmatte anheben, Schnellverschlüsse öffnen und Heckverkleidung abnehmen.


- a Klimaanlage
- c,d Gardine Tür hinten/links
- e,f Gardine Heckscheibe links
- g,h Gardine Heckscheibe rechts
- i,j Gardine Tür hinten/rechts



Relais im Kofferraum links

Bodenmatte anheben, Schnellverschlüsse öffnen und Heckverkleidung abnehmen.

- k Video AUF
- l Entlastung
- m,n,o,p Bildschirmabdeckung
- q Zentralverriegelung
- r Fernstart
- s,t Schublade AUF/ZU
- u Codeschloß/Hubmagnet
- v Telefax



Telefonvorbereitung

Das Fahrzeug ist serienmäßig mit einer Vorbereitung zur Nachrüstung einer Telefonanlage ausgestattet. Die Antenne ist hinten rechts montiert, sowie die Stromversorgung zur Anschlußplatte für das Sende-/Empfangsgerät hinten/links verlegt.

Pflegehinweise

Edelholz

Holzblenden und in Holz ausgeführte Ausstattungen bitte ausschließlich mit feuchtem Lappen reinigen.

Anschließend mit weichem Tuch trocknen.

Lederpflege

Bei dem von BMW verarbeiteten Polsterleder handelt es sich um ein hochwertiges, nach dem neuesten Stand der Verfahrenstechnik bearbeitetes Naturprodukt, dessen Qualitätsstand bei entsprechender Pflege über Jahre hinaus gehalten werden kann.

Da es sich hierbei um ein unverfälschtes Naturprodukt handelt, müssen die Eigenarten, aber auch Einschränkungen im Gebrauch und die besondere Pflege berücksichtigt bzw. in Kauf genommen werden.

Regelmäßige Reinigung und Pflege ist notwendig, denn Staub und Straßenschmutz scheuern in Poren und Falten und führen zu starkem Abrieb sowie zu vorzeitiger Versprödung der Lederoberfläche.

Bei starker Sonneneinstrahlung und längerer Standzeit zur Vermeidung des Ausbleichens lederbezogene Teile diese Teile oder alle Fensterscheiben abdecken

Trikot- oder Wollappen mit Wasser leicht anfeuchten und Lederflächen säubern, ohne das Leder oder die Nahtstellen zu durchfeuchten. Anschließend das getrocknete Leder mit einem sauberen und weichen Tuch nachreiben.

Die gereinigten (lackierten) Lederpolster müssen zur Lederpflege und als Anti-Elektro-Statikum mit Karneol* behandelt werden. Vor Gebrauch gut schütteln und mit einem weichen Lappen dünn auftragen. Nach dem Eintrocknen mit einem sauberen weichen Tuch nachreiben.

Diese Behandlung wird bei normaler Beanspruchung halbjährlich empfohlen.

* beim BMW Service erhältlich

Supplementary Owner's Handbook

Special equipment for
individualised BMW 7 Series models

No claims can be entertained on the basis of the data, illustrations and descriptions in this manual. Subject to errors.

Subject to design, equipment and accessory modifications in the interests of technical development.


This supplementary owner's handbook contains information on optional equipment and special items on your BMW 750iL. It should not be regarded as a substitute for the standard owner's handbook.

The following pages are intended to show you where these special features are installed and how they should be operated.

The equipment on your car depends on the order/delivery specification and national-market versions. In other words, this booklet may contain descriptions of items of special equipment which are not included on your car.

Please read this booklet carefully, so that you can derive maximum benefit from its special equipment features.

Wishing you many a pleasant journey,
BAYERISCHE MOTOREN WERKE AKTIENGESELLSCHAFT




Auxiliary controls on instrument panel

1. ON/OFF switch for central locking system
2. Pushbutton for activating remote-control engine starting
3. OPEN/CLOSE switch for rear left door curtain
4. OPEN/CLOSE switch for rear right door curtain
5. Microphone for intercom to outside
6. Volume control for two-way intercom
7. ON/OFF switch for two-way intercom
8. Speak button for intercom to outside
9. OPEN/CLOSE switch for left rear-window curtain
10. OPEN/CLOSE switch for right rear-window curtain
11. Pushbutton for **Electronic Damping Control (EDC)***
12. Pushbutton for **Automatic Stability Control (ASC)***
13. Pushbutton for **Park Distance Control (PDC)***

9. OPEN/CLOSE switch for left rear-window curtain
10. OPEN/CLOSE switch for right rear-window curtain
11. Pushbutton for **Electronic Damping Control (EDC)***
12. Pushbutton for **Automatic Stability Control (ASC)***
13. Pushbutton for **Park Distance Control (PDC)***


* See standard owner's handbook for operating and functional description.



Auxiliary controls on rear centre console

1. Switch for rear-area air conditioning
2. OPEN/CLOSE switch for rear left door curtain
3. OPEN/CLOSE switch for rear right door curtain
4. OPEN/CLOSE switch for left rear-window curtain
5. OPEN/CLOSE switch for right rear-window curtain
6. Camera zoom switch
7. Screen cover switch
8. OPEN pushbutton for video cassette compartment
9. OPEN/CLOSE safe switch, or extend/retract telefax
10. ON/OFF switch for central locking system
11. Microphone for intercom to outside
12. Speak button for intercom to outside
13. Lock code keys
14. Head restraint adjustment switch, front passenger's seat
15. Seat adjustment switch, front passenger's seat

9. OPEN/CLOSE safe switch, or extend/retract telefax
10. ON/OFF switch for central locking system
11. Microphone for intercom to outside
12. Speak button for intercom to outside
13. Lock code keys
14. Head restraint adjustment switch, front passenger's seat
15. Seat adjustment switch, front passenger's seat



Drawer in rear centre console

Depending on order/delivery specification, the telefax or the safe is located in the drawer.

To open the drawer:
(see auxiliary controls on rear centre console, Page 3).


Telefax unit

The telefax unit is equipped with an acoustic coupler (1).

Important:

The telefax is only operational when the drawer is fully extended.

Consult the separate operating instructions for further information on how to use and operate complete unit.



Safe

Encoding the lock:

You can input your personal secret code (up to seven digits, starting at the left, i.e. the side facing the front of the car) via the illustrated digital display zone, which is only visible when the drawer is open.

Important:

Take care to remember your personal secret code!

Example: 0012000

To open a safe with this code, you need only input the number **12000** via the keys (arrow). Zeroes before the first digit can be ignored.

Each time a key is pressed, a short acoustic signal is given. This acoustic signal does not sound when the last correct digit is input, to indicate that the complete correct code has been input.

If the **OPEN drawer** switch is not pressed within four seconds, the complete code must be input once more.

If the wrong code number has been input, press **R** (reset) key.


The maximum number of attempts to input the correct code is the number of digits in the code plus one. Our example used a five-digit code, as a result of which a total of six attempts can be made.

If the correct code has still not been input after the sixth attempt, no further code can be input for 10 minutes. If any keys are pressed within this period (10 minutes), the lock-out time is extended by the time which has already elapsed.

Note:


When the car is delivered, the code is set to **0000000**.

Release the lock by pressing the digit **0** in the key area (arrow). If the **OPEN drawer** switch is not operated within four seconds, the **0** key must be pressed once more.



Box for tissues


Pull out the box in the direction of arrow, insert a new pack of tissues in the trim, offer up the box to the door trim and fold up.



Front storage compartment

To open: pull handle.

Lock is operated by a master key.



Remote control/remote engine starting system (FSA)

The car's engine can be started from a distance of up to app. 500 m with the remote control device.

Important:

The remote control device only functions when the switch is active (see Page 2, item 9).

Press keys 1 and 4:


Alarm system is deactivated, central locking is deactivated, engine starts.

Press keys 2 and 4:

Attack alarm is sounded.

Press keys 3 and 4:

Anti-theft alarm is sounded, engine cannot be started.



Battery charging socket


When charging via the charging socket (1), both batteries (starter and auxiliary battery) are charged simultaneously.

The batteries can only be connected up by means of a conventional plug connection to DIN 14 690-C.

Note:


When connected up to the car, only recharge the battery with the engine switched off. Charge voltage must not exceed 15 Volts. Charger must be to VDA specification. If in doubt, consult a BMW service station.

See the standard owner's handbook for further details.




Luggage compartment release handle

The luggage compartment lid can be released from the inside by pulling the cord (arrow).



Bulkhead in luggage compartment

To remove the bulkhead, release the knurled bolt (arrow); on models with rear-area air conditioning, the compressor trim must also be dismantled.




Fuses

The special-equipment fuses are located behind the right-hand side trim in the luggage compartment.

Lift up the floor mat, open the quick-release fasteners and remove the side trim.

Use the plastic pincers (in the master fuse box inside the engine compartment, on the left) to pull the fuse of the faulty consumer out of its holder.


A blown fuse can be recognised by its melted metal wire. Replace it by a new fuse with the same rating in Amps.



Relays on right-hand side of luggage compartment

Lift up the floor mat, open the quick-release fasteners and remove the rear trim.


- a Air conditioning
- c, d Curtain, rear door/left
- e, f Curtain, rear window, left
- g, h Curtain, rear window, right
- i, j Curtain, rear door/right



Relays on left-hand side of luggage compartment

Lift up the floor mat, open the quick-release fasteners and remove the rear trim.

- k OPEN video
- l Load relief
- m, n, o, p Screen cover
- q Central locking
- r Remote engine starting
- s, t OPEN/CLOSE drawer
- u Encoded lock/lifting magnet
- v Telefax



Telephone preparation

As part of its standard specification, the car has provision for a telephone to be retro-fitted. The aerial is fitted on the right at the rear and the power supply to the terminal board for transceiver on the rear left.

Care instructions

Real wood equipment

Use only a damp cloth to clean wooden trims and equipment items in real wood.

Wipe dry with a soft cloth.

Leather care

The upholstery leather used by BMW is a natural product of the highest quality, processed by the very latest methods, and will retain its fine appearance for many years if correctly treated.

Since leather is an absolutely natural product, its characteristics and certain restrictions on its use and special care precautions must be noted.

Regular cleaning and care are needed, since dust and dirt, for instance from the roads, collect in pores and creases, cause severe abrasion and can lead to the leather surface becoming prematurely brittle.

If exposed to strong sunlight when the car is parked for a lengthy period, leather-upholstered seats should be covered or the windows blanked off to prevent fading.


To clean, slightly moisten a cotton or woolen cloth with water and rub the leather surface gently without allowing moisture to collect in the seams. Dry and rub down with a clean, soft cloth.

After cleaning, glossy leather surfaces should be treated with Karneol* to protect them and prevent the build-up of a static electrical charge. Shake well and apply a thin coating with a soft cloth. Allow to dry and rub with a clean, soft cloth.

In normal conditions, repeat this treatment every six months.

* Available from BMW service stations.

BMW



THIS MICROFICHE 'SUPPLEMENTARY PARTS CATALOGUE BMW 750IL E32' IS AVAILABLE FOR THE FOLLOWING MODEL:

BMW 750IL 'PERSONALISED'

THIS SUPPLEMENTARY PARTS CATALOGUE CONTAINS INFORMATION ON OPTIONAL EQUIPMENT AND SPECIAL ITEMS.
IT SHOULD NOT BE REGARDED AS A SUBSTITUTE FOR THE STANDARD PARTS CATALOGUE

BMW AG

LIST OF MAIN GROUPS (HG)

HG

00 INSTRUCTIONS

11 ENGINE

12 ENGINE ELECTRICAL SYSTEM

13 FUEL PREPARATION

16 FUEL SYSTEM

17 RADIATOR

18 EXHAUST SYSTEM

21 CLUTCH

23 MANUAL GEARBOX

24 AUTOMATIC GEARBOX

26 DRIVE SHAFTS

27 AUXILIARY TRANSMISSION

31 FRONT AXLE

32 STEERING

33 REAR AXLE

34 BRAKES

HG

35 PEDAL CLUSTER

36 WHEELS

41 BODY SHEET METAL

51 VEHICLE EQUIPMENT

52 SEATS

54 SLIDING ROOF

61 VEHICLE ELECTRICAL SYSTEM

62 INSTRUMENTS

63 LIGHTING SYSTEM

64 HEATING AND AIR CONDITIONER

65 RADIO AND SPECIAL APPLIANCES

71 ACCESSORIES AND TRIM PARTS

72 ACCESSORIES AND TRIM PARTS

EXPLANATION OF TEXT PAGES.

1. ILLUSTRATION NUMBER -COLUMN

1 TO 40 THESE ARE THE ILLUSTRATION NUMBERS UNDER WHICH THIS PART IS SHOWN.
-- NOT ILLUSTRATED

2. ILLUSTRATION NUMBER WITHOUT TEXT (PART-NUMBER)

ILLUSTRATION NUMBERS, WHICH ARE NOT SPECIFIED IN THE TEXT-PART MUST BE TAKEN FROM THE STANDARD PARTS CATALOGUE.
(PLEASE PAY ATTENTION TO ADDITIONAL INFORMATION)

REASON: THIS MICROFICHE IS AN SUPPLEMENTARY PARTS CATALOGUE.

ADDITIONAL INFORMATION: PARTS THAT ARE IDENTICAL WITH THE STANDARD VEHICLE (BUT COVERED IN LEATHER OR ANY OTHER NON-STANDARD MATERIAL) SHOULD BE ORDERED WITH THE STANDARD PARTS NUMBER (MICROFICHE 730 -750IL) TOGETHER WITH INTERIOR TRIM -, OR COLOUR CODE INFORMATION BY TELEX/TELEFAX.

3. DESIGNATION -COLUMN

CORRESPONDS TO STANDARD PARTS CATALOGUE

4. MODEL -COLUMN

1 TO 9 REQUIRED QUANTITY
x RUNNING METER OR QUANTITY ABOVE 9

5. 'SYMBOL' -COLUMN

UPH.CODE: WHEN ORDERING SPARE PARTS, INTERIOR TRIM -, OR COLOUR CODE INFORMATION MUST BE QUOTED BY TELEX/TELEFAX.

6. STARTING / DISCONTINUATION -COLUMN

INSTALLATION PERIOD WITH MONTHLY AND ANNUAL FIGURES

7. PART NUMBER -COLUMN

CODE LETTER PLACED BEHIND THE PART NUMBER

Z RETRO ACTIV EXCHANGEABLE - TO COMBINE OLD AND NEW COMPONENTS
A PART NUMBER IS INTERCHANGEABLE WITH THE PART NUMBER IN THE NEXT LINE. THE APPLICATION OF THE PART NUMBER OLD IS ONLY POSSIBLE UP TO THE BRAKE POINT. (SEE RUN OUT COLOUMEN IN PARTS MICRO FICHE)
E PART NUMBER IS NO LONGER AVAILABLE FROM THE FACTORY (DISCONTINUED).
H PART NUMBER CAN BE USED WITH THE NEIGHBOURING PART NUMBER ALSO MARKED WITH 'H'.

32



32

STEERING

001
002


INSTRUCTIONS
STEERING LOCK/IGNITION SWITCH

Teile, die mit dem Serienfahrzeug identisch, jedoch mit Leder oder mit Materialien abweichend zum Serienfahrzeug bezogen sind, müssen mit der Serienteilenummer (Microfilm 730i - 750iL) unter Angabe der Innenausstattung bzw. Farbcode per Telex oder Telefax bestellt werden.

Parts identical with the standard vehicle, however, covered with leather or material other than that of the standard vehicle must be ordered with the standard parts number (microfilm 730i - 750iL), by indicating the interior equipment and/or colour code, by telex or telefax.

32/2239

32-001	BMW 750iL PER E32	750iL PER										Symbol	from	up to	32/2239
INSTRUCTIONS =====															



32/0420

32-002

BMW 750iLPER E32


32/0420

STEERING LOCK/IGNITION SWITCH
 1 STEERING LOCK

1

32 32 1 158 850

41



41

BODY PARTS

001

CENTRAL LOCKING SYSTEM

51




51

VEHICLE TRIM

001
002
003
004
005
006
007

STORING PARTITION FRONT
CENTER CONSOLE
SET WOOD STRIPS
TISSUES-BOX
LINING COLUMN
FLOOR MATS VELOURS
PACKAGE SHELF



41/2243

41-001

BMW 750ILPER E32


41/2243

CENTRAL LOCKING SYSTEM
=====

4 ACTUATOR

2

51 26 1 389 695



51/2239

51-001

BMW 750iLPER E32

51/2239

STORING PARTITION FRONT

- 1 COVERING STORING PARTITION MIDDLE FRONT
 2 SWITCH COVERING
 3 CAP
 4 FILLISTER HEAD SELF-TAPPING SCREW ST4,2x19
 5 FLAT WASHER 4,3
 6 FILLISTER HEAD SELF-TAPPING SCREW ST4,2x19
 7 FLAT WASHER 4,3
 8 BODY NUT ST4,2-5
 9 PLUG
 ONLY APPLIES TO
 CURTAIN OPEN/CLOSE
 10 SWITCH
 11 SWITCH HEAD REST REAR
 12 SWITCH REMOTE START

750iLPER

Symbol

From

Up to

UPH.CODE
 UPH.CODE
 UPH.CODE

UPH.CODE

51 16 1 958 966
 51 16 1 958 419
 51 16 1 964 967
 07 11 9 907 950
 07 11 9 936 412
 07 11 9 906 772
 07 11 9 936 412
 07 12 9 925 710
 64 11 1 368 498

61 12 1 390 895

61 31 1 379 078
 61 31 1 379 540



51-002		BMW 750ILPER E32		750ILPER		symbol		from		up to		51/2290	
CENTER CONSOLE =====													
1	CENTER CONSOLE	TV/VIDEO		1		UPH.CODE						65 50 2 134 374	
2	COVERING VIDEO RECORDER			1		UPH.CODE						61 13 2 131 897	




51-003

BMW 750ILPER E32

51/1610

51-003		BMW 750ILPER E32		750ILPER		symbol		from		up to		51/1610	
SET WOOD STRIPS -----													
1	SET WOOD STRIPS	WURZELHOLZ		1								51 41 2 134 656	
1	SET WOOD STRIPS	ROSENHOLZ		1								51 41 2 134 657	
1	SET WOOD STRIPS	PAPPELHOLZ		1								51 41 2 134 658	



51/2291


51-004

BMW 750ILPER E32

51/2291

		750ILPER										Symbol	From	Up to					
TISSUES-BOX																			

1	TISSUES-BOX LEFT											UPH.CODE			51	42	2	134	885
1	TISSUES-BOX RIGHT											UPH.CODE			51	42	2	134	884
2	FILLISTER HEAD SELF-TAPPING SCREW														07	11	9	907	802
3	BODY NUT														07	12	9	925	709
4	PLATE														51	42	2	134	975
5	PLUG														51	47	1	911	992
6	WIRING CIGAR LIGHTER REAR														61	12	2	131	901
7	LIGHTER SOCKET														61	34	1	367	690
8	CLAMPING BUSH														61	34	1	362	968
9	LIGHTER ELEMENT														61	34	1	375	967
10	BULB														63	31	1	382	547



51/2268


51-005

BMW 750ILPER E32

51/2268

LINING COLUMN

Symbol	from	up to
1 COVERING COLUMN-REAR LEFT	1	51 43 2 134 677
1 COVERING COLUMN-REAR RIGHT	1	51 43 2 134 678
2 BLIND PLATE	2	51 43 2 134 679
3 RECESSED OVAL HEAD SHEET-METAL SCREW ST4,2X32	2	07 11 9 902 475
4 FILLISTER HEAD SELF-TAPPING SCREW ST4,8X45	4	07 11 9 906 771
5 FRESH AIR GRILLE REAR ROOM	2	64 22 2 134 908



51/2141

51-006


BMW 750ILPER E32

51/2141

FLOOR MATS VELOURS
 3 SET FLOOR MATS LAMPSKIN

1

51 47 2 134 565



51/2289

51-007

BMW 750ILPER E32

51/2289

BMW 750ILPER										Symbol	From	Up to	
PACKAGE SHELF ***** ONLY APPLIES TO BMW STEREO 1 PACKAGE SHELF ONLY APPLIES TO HIFI SYSTEM PIONEER 1 PACKAGE SHELF 2 CAP													
								1		UPH.CODE			51 46 2 134 523
								1		UPH.CODE			51 16 2 134 528
								2		UPH.CODE			51 41 1 869 870

51



51 VEHICLE TRIM


008 - 010 CURTAIN
011 TRUNK TRIM

52



52 SEATS

001 SEAT PANEL REAR/FOLDINGTABLE
002 FOOT REST
003 - 004 REAR CENTRE CONSOLE




51-008

BMW 750iLPER E32

51/2292

		750iLPER	Symbol	From	Up to	51/2292				
CURTAIN										
1	INSTALLING SET ELECTR. CURTAIN	ANTHRAZIT	1			51	16	2	134	489
1	INSTALLING SET ELECTR. CURTAIN	SILBERGRAU	1			51	16	2	134	493
1	INSTALLING SET ELECTR. CURTAIN	KARMESINROT	1			51	16	2	134	498
1	INSTALLING SET ELECTR. CURTAIN	BRASIL	1			51	16	2	134	503
1	INSTALLING SET ELECTR. CURTAIN	MAGNOLIA	1			51	16	2	134	508
1	INSTALLING SET ELECTR. CURTAIN	WEISS	1			51	16	2	134	513
1	INSTALLING SET ELECTR. CURTAIN	NATUR	1			51	16	2	134	518
1	INSTALLING SET ELECTR. CURTAIN	ULTRAMARIN	1			51	16	2	134	480
2	CURTAIN LEFT	ANTHRAZIT	1			51	46	2	134	819
2	CURTAIN LEFT	SILBERGRAU	1			51	46	2	134	821
2	CURTAIN LEFT	KARMESINROT	1			51	46	2	134	823
2	CURTAIN LEFT	BRASIL	1			51	46	2	134	827
2	CURTAIN LEFT	MAGNOLIA	1			51	46	2	134	829
2	CURTAIN LEFT	WEISS	1			51	46	2	134	833
2	CURTAIN LEFT	NATUR	1			51	46	2	134	837
2	CURTAIN LEFT	ULTRAMARIN	1			51	46	2	134	839
3	CURTAIN RIGHT	ANTHRAZIT	1			51	46	2	134	820
3	CURTAIN RIGHT	SILBERGRAU	1			51	46	2	134	822
3	CURTAIN RIGHT	KARMESINROT	1			51	46	2	134	824
3	CURTAIN RIGHT	BRASIL	1			51	46	2	134	828
3	CURTAIN RIGHT	MAGNOLIA	1			51	46	2	134	830
3	CURTAIN RIGHT	WEISS	1			51	46	2	134	834
3	CURTAIN RIGHT	NATUR	1			51	46	2	134	838
3	CURTAIN RIGHT	ULTRAMARIN	1			51	46	2	134	840




51/2292

51-009

BMW 750ILPER E32

51/2292

		750ILPER	Symbol	from	up to		
CURTAIN							
4	CURTAIN LEFT	ANTHRAZIT	1			51	16 8 111 215
4	CURTAIN LEFT	SILBERGRAU	1			51	16 2 133 363
4	CURTAIN LEFT	KARMESINROT	1			51	16 2 134 825
4	CURTAIN LEFT	BRASIL	1			51	16 2 133 433
4	CURTAIN LEFT	MAGNOLIA	1			51	16 2 134 831
4	CURTAIN LEFT	WEISS	1			51	16 2 134 835
4	CURTAIN LEFT	NATUR	1			51	16 2 133 399
4	CURTAIN LEFT	ULTRAMARIN	1			51	16 2 134 841
4	CURTAIN RIGHT	ANTHRAZIT	1			51	16 8 111 216
4	CURTAIN RIGHT	SILBERGRAU	1			51	16 2 133 362
4	CURTAIN RIGHT	KARMESINROT	1			51	16 2 134 826
4	CURTAIN RIGHT	BRASIL	1			51	16 2 133 432
4	CURTAIN RIGHT	MAGNOLIA	1			51	16 2 134 832
4	CURTAIN RIGHT	WEISS	1			51	16 2 134 836
4	CURTAIN RIGHT	NATUR	1			51	16 2 133 400
4	CURTAIN RIGHT	ULTRAMARIN	1			51	16 2 134 842
5	CURTAIN RAIL DOOR LEFT	ANTHRAZIT	1			51	16 2 133 593
5	CURTAIN RAIL DOOR LEFT	SILBERGRAU	1			51	16 2 134 789
5	CURTAIN RAIL DOOR LEFT	KARMESINROT	1			51	16 2 134 791
5	CURTAIN RAIL DOOR LEFT	BRASIL	1			51	16 2 134 793
5	CURTAIN RAIL DOOR LEFT	MAGNOLIA	1			51	16 2 134 795
5	CURTAIN RAIL DOOR LEFT	WEISS	1			51	16 2 134 797
5	CURTAIN RAIL DOOR LEFT	NATUR	1			51	16 2 134 799
5	CURTAIN RAIL DOOR LEFT	ULTRAMARIN	1			51	16 2 134 801
5	CURTAIN RAIL DOOR RIGHT	ANTHRAZIT	1			51	16 2 133 588
5	CURTAIN RAIL DOOR RIGHT	SILBERGRAU	1			51	16 2 134 790
5	CURTAIN RAIL DOOR RIGHT	KARMESINROT	1			51	16 2 134 792
5	CURTAIN RAIL DOOR RIGHT	BRASIL	1			51	16 2 134 794
5	CURTAIN RAIL DOOR RIGHT	MAGNOLIA	1			51	16 2 134 796
5	CURTAIN RAIL DOOR RIGHT	WEISS	1			51	16 2 134 798
5	CURTAIN RAIL DOOR RIGHT	NATUR	1			51	16 2 134 800
5	CURTAIN RAIL DOOR RIGHT	ULTRAMARIN	1			51	16 2 134 802




51-010

BMW 750ILPER E32


51/2292

		750ILPER	Symbol	from	up to				
CURTAIN =====									
6	CURTAIN RAIL	ANTHRAZIT	1			51	46	2	134 491
6	CURTAIN RAIL	SILBERGRAU	1			51	46	2	134 496
6	CURTAIN RAIL	KARMESINROT	1			51	46	2	134 501
6	CURTAIN RAIL	BRASIL	1			51	46	2	134 506
6	CURTAIN RAIL	MAGNOLIA	1			51	46	2	134 511
6	CURTAIN RAIL	WEISS	1			51	46	2	134 516
6	CURTAIN RAIL	NATUR	1			51	46	2	134 521
6	CURTAIN RAIL	ULTRAMARIN	1			51	46	2	134 483
7	CURTAIN RAIL	ANTHRAZIT	1			51	46	2	134 803
7	CURTAIN RAIL	SILBERGRAU	1			51	46	2	134 805
7	CURTAIN RAIL	KARMESINROT	1			51	46	2	134 807
7	CURTAIN RAIL	BRASIL	1			51	46	2	134 809
7	CURTAIN RAIL	MAGNOLIA	1			51	46	2	134 811
7	CURTAIN RAIL	WEISS	1			51	46	2	134 813
7	CURTAIN RAIL	NATUR	1			51	46	2	134 815
7	CURTAIN RAIL	ULTRAMARIN	1			51	46	2	134 817
8	DRIVE CURTAIN DOOR LEFT		1			51	16	2	133 595
8	DRIVE CURTAIN DOOR RIGHT		1			51	16	2	133 594
8	DRIVE CURTAIN REAR LEFT		1			67	65	2	133 583
8	DRIVE CURTAIN REAR RIGHT		1			67	65	2	133 584



52/2203A

52-001		BMW 750ILPER E32		750ILPER										Symbol	from	up to	52/2203
SEAT PANEL REAR/FOLDINGTABLE		-----															
2	FOLDINGTABLE													2	UPH.CODE		52 10 2 134 978




52/0916

52-002

BMW 750ILPER E32

52/0916

		750ILPER										Symbol	from	up to	
1	FOOT REST ***** FOOT REST LAMBSKIN								2						52 10 2 134 566




52/2282

52-003

BMW 750ILPER E32

52/2282

		Symbol	from	to
REAR CENTRE CONSOLE				
1	REAR CENTRE CONSOLE			
2	BULB			
3	GLOVE BOX LIGHT			
4	HEX BOLT WITH WASHER			
5	SWITCH PANEL			
ONLY APPLIES TO SAFE				
5	SWITCH PANEL			
ONLY APPLIES TO REAR-AREA AIR CONDITIONING SYSTEM				
5	SWITCH PANEL			
ONLY APPLIES TO SAFE/REAR-AREA AIR CONDITIONING SYSTEM				
5	SWITCH PANEL			
ONLY APPLIES TO SWITCH BLOWER				
6	SWITCH PANEL			
7	PLUG			
ONLY APPLIES TO CENTRAL LOCKING SYSTEM ON/OFF				
SAFE OPEN/CLOSE				
SCREEN COVER				
CAMERA ZOOM				
8	SWITCH			
ONLY APPLIES TO VIDEO CASSETTE COMPARTMENT OPEN				
9	SWITCH			



52/2282

52-004

BMW 750ILPER E32

52/2282

		Symbol	From	Up to					
REAR CENTRE CONSOLE									

ONLY APPLIES TO									
CURTAIN OPEN/CLOSE									
10	SWITCH				4				61 31 2 131 729
11	COLD COMPARTMENT	SCHWARZ			1				82 11 2 134 552
11	COLD COMPARTMENT	KARMESINROT			1				82 11 2 134 553
11	COLD COMPARTMENT	SILBERGRAU HELL			1				82 11 2 134 554
11	COLD COMPARTMENT	PERGAMENT			1				82 11 2 134 555
11	COLD COMPARTMENT	PERGAMENT HELL			1				82 11 2 134 556
11	COLD COMPARTMENT	ULTRAMARIN			1				82 11 2 134 557
11	COLD COMPARTMENT	BRASIL			1				82 11 2 134 558
11	COLD COMPARTMENT	ANTHRHAZIT			1				82 11 2 134 559
12	BAR PACKAGE TRAY				1				82 11 2 134 910
13	HEX BOLT WITH WASHER	M6x60-Z3			1				07 11 9 913 001
14	BLIND PLUG	D=12MM			1				51 71 8 110 199
15	SHEET METAL SCREW	B4,2x13			1				51 16 1 948 970
16	CAP	SCHWARZ			2				51 16 1 949 793
16	CAP	KARMESINROT			2				51 16 8 117 088
16	CAP	SILBERGRAU HELL			2				51 16 8 140 432
16	CAP	PERGAMENT			2				51 16 8 140 434
16	CAP	PERGAMENT HELL			2				51 16 8 140 435
16	CAP	ULTRAMARIN			2				51 16 8 140 433
16	CAP	BRASIL			2				51 16 8 140 436
17	BODY NUT	ST4,2-4			2				07 12 9 925 708

UPH. CODE

61




61

VEHICLE ELECTRIC

- 001 MAIN CABLE HARNESS
- 002 DOOR CABLE HARNESSES
- 003 WIRING SETS
- 004 VARIOUS RELAYS
- 005 CHARGING SOCKET
- 006 STEERING COLUMN SWITCH


62



62


INSTRUMENTS

- 001 THEFT ALARM/INFRARED CONTROL



61/0104A

61-001	BMW 750iLPER E32		750iLPER				Symbol	from	up to	61/0104
MAIN CABLE HARNESS ===== 3 CABLE HARNESS SECTOR REAR			1							61 11 8 350 645



61/0158

61-002

BMW 750ILPER E32

61/0158

DOOR CABLE HARNESSSES

- 1 WIRING DRIVERS SIDE
- 1 WIRING CO-DRIVERS SIDE
- 2 WIRING REAR LEFT
- 2 WIRING REAR RIGHT

750ILPER

Symbol


from

up to

1
1
1
1

08/91
08/91

61 12 1 388 895
61 12 2 131 735
61 12 2 131 961
61 12 2 131 962




61/2239

61-003

BMW 750iLPER E32

61/2239

		750iLPER										Symbol	From	Up to					
WIRING SETS																			
1	WIRING BASIS MIDDLE EAST														61	12	2	131	710
2	WIRING REAR DOOR														61	12	2	131	704
3	WIRING GONG														61	12	2	131	993
4	BRACKET FUSE CARRIER														61	13	2	131	764
5	HEX NUT														34	41	1	151	209
6	SUPPORT														61	13	1	382	541
7	FUSE														61	13	1	370	987
7	FUSE														61	13	1	372	626
7	FUSE														61	13	1	372	628
8	HEX NUT														34	41	1	151	209
9	HEX BOLT														07	11	9	913	443
10	TOOTH WASHER														07	11	9	936	133



61/0462C

61-004

BMW 750ILPER E32


61/0462

VARIOUS RELAYS

1 RELAY
9 RELAY

X
X

61 31 1 378 297
61 36 1 393 415



61/2240

61-005

BMW 750iLPER E32

61/2240

CHARGING SOCKET

- 1 PLUG TERMINAL
- 2 PLUG-IN SOCKET
- 3 WIRING CHARGING SOCKET
- 4 ADAPTOR
- 5 BRACKET
- 6 HEX BOLT
- 7 CSK.FILLISTER HEAD SCREW
- 8 WAVE WASHER
- 9 HEX NUT

C16

M5x10
M5x16
B5
M5


750iLPER

Symbol

from

up to

07	11	9	909	890
61	12	1	379	224
61	12	2	131	714
61	31	1	382	083
61	13	1	390	669
07	11	9	913	271
07	11	9	928	488
07	11	9	932	047
07	11	9	922	038



61/0602 E

61-006


BMW 750ILPER E32

61/0602

STEERING COLUMN SWITCH
 2 SWITCH TURN SIGNAL, DIP-DIM CONTROL

1

61 31 1 382 860



1

62/0118

62-001

BMW 750ILPER E32

62/0118

THEFT ALARM/INFRARED CONTROL
 1 REMOTE START SYSTEM

1

65 61 1 390 807


64



64 HEATER AND AIR CONDITIONING SYSTEM


001 REAR-AREA AIR CONDITIONING SYSTEM

65



65 RADIO AND SPECIAL EQUIPMENT

001 RADIO/CD PIONEER
002 - 003 SINGLE COMPONENTS HIFI SYSTEM PIONEER
004 ANTENNA RADIOTELEPHONE
005 ANTENNA TV
006 ANTENNA REMOTE START SYSTEM
007 TV/VIDEO SYSTEM




1


65/2242

65-001	BMW 750ILPER E32	750ILPER					Symbol	from	up to	65/2242
1	RADIO/CD PIONEER ===== RADIO/CD PIONEER		1							65 12 2 131 731



65-002		BMW 750ILPER E32		750ILPER		symbol		from		up to		65/2243	
SINGLE COMPONENTS HIFI SYSTEM PIONEER													
=====													
1	WIRING SET	RADIO HIFI										61	12 2 131 708
2	WIRING	RADIO CD										61	12 2 131 712
3	TUBING	RADIO										62	12 1 390 062
4	LOUDSPEAKER	HIFI/SOUND SYST										65	13 1 377 772
5	LOUDSPEAKER	HIFI SYSTEM										65	13 1 379 962
6	LOUDSPEAKER BASS											65	13 2 131 768
7	FREQUENCY SWITCH FRONT											65	12 2 131 743
8	BRACKET FREQUENCY SWITCH											65	12 2 131 765
9	FILLISTER HEAD SELF-TAPPING SCREW	ST3.5x13-Z1										07	11 9 907 915 E
10	BODY NUT	ST3.5-2										07	12 9 925 714

[illegible]



65/2240

65-005

BMW 750iLPER E32

65/2240


ANTENNA TV *****

- 1 ANTENNA TV
- 2 BRACKET
- 3 RUBBER GROMMET
- 4 HEX HEAD SCREW
- 5 BODY NUT
- 6 HEX HEAD SCREW
- 7 ANTENNA CABLE


B4,8X9,5
ST4,8-1
B4,2X13
TV

1
1
1
1
1
1
2
1

65 21 2 131 740
65 61 8 350 660
21 52 2 072 270
07 11 9 916 812
07 12 9 925 735
07 11 9 916 913
61 13 2 131 899



65-006		BMW 750ILPER E32		750ILPER		Symbol		From		Up to		65/2241	
ANTENNA REMOTE START SYSTEM *****				1								65 21 2 131 741	
1 ANTENNA REMOTE START SYSTEM													



65/2239

65-007

BMW 750iLPER E32

65/2239

TV/VIDEO SYSTEM


- 1 TV MONITOR
- 2 VIDEO-RECORDER
- 3 CONNECTION CABLE
- 4 CONNECTION CABLE
- 5 WIRING SET

RADIO/TV

1
1
1
1
1
1

65 50 2 131 701
65 50 2 131 884
65 50 2 131 887
65 50 2 131 898
61 12 2 131 718

65




65

RADIO AND SPECIAL EQUIPMENT

008
009
010
011
012

REAR CENTRE CONSOLE TELEFAX
REAR CENTRE CONSOLE SAFE
VIDEO-CAMERA
INSTALLING SET 2, BATTERY
CONTROL UNIT BASE PLATE



65/2245

65-008

BMW 750ILPER E32


65/2245

REAR CENTRE CONSOLE TELEFAX

- 1 TELEFAX
- 2 BRACKET ACOUSTIC COUPLER
- 3 SET RECESS.OVAL HEAD SHEET-METAL SCREW20 ST3.5x13
- 4 BODY NUT ST3.5-2
- 5 STRIP

1
1
2
2
1

65 61 2 131 831
65 61 2 137 008
07 50 9 063 310
07 12 9 925 714
65 61 2 134 849



65/2244

65-009

BMW 750ILPER E32

65/2244

REAR CENTRE CONSOLE SAFE

- 1 LOCK CODE KEYS
- 2 REAR CENTRE CONSOLE SAFE
- 3 BULB
- 4 GLOVE BOX LIGHT
- 5 SOLENOID SWITCH

12V 5W

750ILPER


Symbol

from

up to

UPH. CODE

61	35	2	131	852
51	16	2	135	046
07	11	9	978	340
63	31	1	372	586
61	31	1	364	935



65/2238

65-010

BMW 750ILPER E32

65/2238

VIDEO-CAMERA


- 1 VIDEO-CAMERA
- 2 INSTALLING SET VIDEO CAMERA
- 3 BRACKET VIDEO CAMERA
- 4 FLAT WASHER
- 5 HEX NUT
- 6 COVERING CAP VIDEO CAMERA
- 7 BODY NUT
- 8 FILLISTER HEAD SELF-TAPPING SCREW

40/8,5
M6
ST4,2-1
ST3,5x19-Z1

1
1
1
8
4
1
3
3

UPH. CODE

65	52	2	131	749
65	12	2	131	700
65	52	2	131	883
11	14	1	288	689
34	41	1	151	209
51	47	2	134	907
07	12	9	925	709
07	11	9	907	802



65/2236

65-012

BMW 750iLPER E32

65/2236

		750iLPER	Symbol	from	to	
CONTROL UNIT BASE PLATE						
=====						
1	CONTROL UNIT BASE PLATE		UPH.CODE			51 46 2 134 690
ONLY APPLIES TO REAR-AREA AIR CONDITIONING SYSTEM						
1	CONTROL UNIT BASE PLATE		UPH.CODE			51 64 2 134 684
ONLY APPLIES TO HIFI SYSTEM PIONEER						
1	CONTROL UNIT BASE PLATE		UPH.CODE			51 46 2 134 882
ONLY APPLIES TO REAR-AREA AIR CONDIT-/PIONEER SYSTEM						
1	CONTROL UNIT BASE PLATE		UPH.CODE			51 46 2 134 883
2	CONTROL UNIT 20KM/H -RECOGNITION					61 35 2 131 830
3	HEX BOLT WITH WASHER	M5X12-Z1				07 11 9 915 002
4	CONTROL UNIT CAMERA					65 52 2 131 896
5	TV TUNER					65 50 2 131 886
6	BRACKET TV-TUNER					65 50 2 131 892
7	HEX BOLT	M5X10				07 11 9 913 109
8	INTERFACE BOX TV					65 50 2 131 885
9	BRACKET REMOTE START					65 61 2 131 895

BMW AG

